

Carbon Monoxide Meter CM-1101

APPLICATIONS & FEATURES

The Carbon Monoxide Meter detects the presence of carbon monoxide (CO) and measures concentrations between 1-1000 parts per million (PPM).

The Meter indicates the presence of carbon monoxide in two ways:

- By a reading on the LCD in PPM.
- By a beeper tone.

The Meter indicates the presence of CO by a reading on the LCD and a beeper tone. The beeper functions much like clicking of a Geiger counter: Above 200 PPM, the beeper sounds continuously with the concentration of CO. From 35 PPM to 200 PPM, the beeper sounds continuously with the Concentration of CO.

Features:

- Audio Alarm
- Direct Readout of CO concentration in parts per million, PPM.



TECHNICAL SPECIFICATION		CM-1101
Temperature	Operating: Storage::	0° to + 50° C -30° to + 60° C
Operating humidity		0-99% Relative humidity (non-condensing)
Maesurement Range		0 to 1000PPM
Measurement Resolution		1PPM
Accuracy		±5% or ± 10 PPM
Warm up period		<2 seconds
Battery		9V IEC 6LR61, or equivalent.
Auto power off		Meter automatically shuts down after 15 minutes of inactivity
Sensor type		Stabilized electrochemical Gas-specific (CO)
Typical sensor life		3 years

Complete with following accessories:
9 Volt battery and Carrying Case



- Do not use the Meter as a personal safety monitor.
- Learn and recognize the effects of CO poisoning.